

Vector™ Multi-Cook Oven

Deluxe Control

| | |
|--------|---------|
| VMC-H2 | VMC-H2H |
| VMC-H3 | VMC-H3H |
| VMC-H4 | VMC-H4H |



Structured Air Technology™

MN-46295-EN

For the most current manual, visit alto-shaam.com

REV.02
2/20

EN



Manufacturer's Information

Copyright

© Copyright 2/20 by Alto-Shaam, Inc.

All rights reserved.

This manual or any portion thereof may not be reproduced or used in any manner whatsoever without the express written permission of Alto-Shaam, Inc.

Trademarks

All trademarks referenced in this documentation are the property of their respective owners.

Manufacturer

Alto-Shaam, Inc.

P.O. Box 450

W164 N9221 Water Street

Menomonee Falls, WI 53052

Original instructions

The content in this manual is written in American English.

Enjoy your Alto-Shaam Vector Oven!

Structured Air Technology™

The Alto-Shaam Vector Oven features Structured Air Technology, giving you two, three or four ovens in one. It gives you the flexibility to simultaneously cook a variety of menu items with no flavor transfer. It provides the ability to control temperature, fan speed, and time in each individual oven chamber.

Cook up to twice the food than a traditional convection oven, with no microwaves, and no water.

Extend Your Manufacturer's Warranty

Register

Register your Alto-Shaam appliance online. Registering your appliance ensures prompt service in the event of a warranty claim. You will also receive direct notifications of software updates and additional product information.

Your personal information will not be shared with any other company.

www.alto-shaam.com/warranty

Alto-Shaam 24/7 Emergency Repair Service

Call

Call 800-558-8744 to reach our 24-hour emergency service call center for immediate access to local authorized service agencies outside standard business hours. The emergency service access is provided exclusively for Alto-Shaam equipment and is available throughout the United States through Alto-Shaam's toll free number.

Availability

Emergency service access is available seven days a week, including holidays.

This page intentionally left blank.

Manufacturer’s Information 2

Foreword 3

 Enjoy your Alto-Shaam Vector Oven! 3

 Extend Your Manufacturer’s Warranty 3

 Alto-Shaam 24/7 Emergency Repair Service 3

Table of Contents 5

Safety 7

 The Meaning of Signal Words 7

 Appliance Description and Intended Use. 8

 Safety Precautions. 9

Labels 13

 Label Locations 13

Installation 17

 Dimension Drawings 17

 How to Receive the Appliance 18

 How to Unpack the Oven 19

 Vector Pre-Installation Checklist. 20

 Installation Checklist 24

 How to Install the Oven (60 Hz Cord and Plug Models). 26

 How to Install the Oven (60 Hz Models Without Cords or Plugs) . . . 29

 How to Install the Oven (50 Hz Models Without Cords or Plugs) . . . 34

 How to Install the Oven on a Stand 40

 How to View and Set up Network Connections 42

Operation 45

 How to Turn On and Turn Off the Oven 45

 How to Preheat the Oven. 46

 How to Cook with Programmed Recipes 48

 How to Cook in Manual Mode 50

 How to Cool Down the Oven. 53

 How to Create a Recipe. 54

 How to Modify, Duplicate, or Delete a Recipe 58

 How to Load Recipes from a USB Drive. 61

 How to Save Recipes to a USB Drive 63

 How to Update Software with a USB Drive 65

 How to Change the Home Screen 67

 How to Change the Temperature Scale. 69

 How to Enable the Handle Light. 71

 How to View Oven Information 72

 How to Download HACCP Data 73

| | |
|---|-----------|
| Maintenance | 75 |
| Maintenance Schedule | 75 |
| How to Clean the Oven. | 76 |
| Troubleshooting | 81 |
| Error Codes | 81 |
| What to do if the Fan Indicator Light Illuminates | 82 |
| What to do if the High Limit Screen Displays | 83 |
| Cheflinc.alto-shaam.com is not Available on your Device | 84 |
| Cannot Connect to cheflinc.alto-shaam.com | 85 |
| The Oven is not Displayed on the Dashboard | 86 |
| Unable to Assign Recipes from the Dashboard to Ovens in the Field | 87 |
| Notifications | 89 |
| Notifications | 89 |
| Warranty | 93 |
| Warranty | 93 |

The Meaning of Signal Words

This manual contains signal words where needed. These signal words must be obeyed to reduce the risk of death, personal injury, or equipment damage. The meaning of these signal words is explained below.

**DANGER**

Danger indicates a hazardous situation which, if not avoided, will result in serious injury or death.

**WARNING**

Warning indicates a hazardous situation which, if not avoided, could result in serious injury or death.

**CAUTION**

Caution indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Notice indicates a situation which, if not avoided, could result in property damage.




NOTE: Note indicates additional information that is important to a concept or procedure.

Appliance Description and Intended Use

Structured Air Technology™

Alto-Shaam Vector's Structured Air Technology system allows for multiple, unique cooking chambers within the same oven. Air is delivered by a blower located in the rear of each cooking chamber. Air travels vertically through the jet plates into each chamber. The food product is blown with hot air from above and below. Structured Air plates at the top and bottom of the oven complete the upper and lower cooking chambers. Each cooking chamber is independent from the other and includes its own blower and heat source. The operator can select the optimal cooking temperature, air velocity, and cook time for each chamber either manually or through programmed recipes.




5:30



60%



400°



VMC-TS-000271

Configurations

The Vector H Series is available in three configurations: two-, three-, and four-chamber.

Intended use

The Vector series ovens are intended to cook and warm food only. Any other use is prohibited.

Residual risks

This oven is manufactured using ISO-certified processes. The oven is designed with maximum safety in mind; however, there are residual risks to operators of this oven. Residual risks include exposure to heat and exposure to hot food products.

Possible misuse

Misuse of this oven includes loading the oven with anything other than a food product. Misuse also includes heating or cooking any food product that contains alcohol or other flammable substance.

Safety Precautions

Before you begin

Read and understand all instructions in this manual.

Electrical precautions

Obey these electrical precautions when using the appliance:

- Connect the appliance to a properly grounded outlet. Do not use the appliance if it is not properly grounded. Consult an electrician if there is any doubt that the outlet used is properly grounded.
 - Keep the cord away from hot surfaces.
 - Do not attempt to service the appliance or its cord and plug.
 - Do not operate the appliance if it has a damaged cord or plug.
 - Do not immerse the cord or plug in water.
 - Do not let the cord hang over the edge of a table or counter.
 - Do not use an extension cord.
-

Usage precautions

Obey these usage precautions when using the appliance:

- Only use this appliance for its intended use of heating or cooking.
 - Always keep liquids, or foods that can become liquid when heated, level and at or below eye level where they can be seen.
 - Use utensils and protective clothing such as dry oven mitts when loading and unloading the appliance.
 - Use caution when using the appliance. Floors adjacent to the appliance may become slippery.
 - Do not cover or block any of the openings of this appliance.
 - Do not cover racks or any other part of this appliance with metal foil.
 - Do not use this appliance near water such as a sink, in a wet location, near a swimming pool, or similar locations.
 - Do not unplug or disconnect the appliance immediately after cooking. The cooling fans must stay on to protect electrical components.
-

Maintenance precautions

Obey these maintenance precautions when maintaining the appliance:

- Obey precautions in the manual, on tags, and on labels attached to or shipped with the appliance.
- Only clean the appliance when the main disconnect switch is in the OFF position.
- Do not store the appliance outdoors.
- Do not clean the appliance with metal scouring pads.
- Do not use corrosive chemicals when cleaning the appliance.
- Do not use a hose or water jet to clean the appliance.
- Do not use the appliance cavity for storage.
- Do not leave flammable materials, cooking utensils, or food inside the appliance when it is not in use.
- Do not remove the top cover or side panels. There are no user-serviceable components inside.

Operator training

All personnel using the appliance must have proper operator training. Before using the appliance:

- Read and understand the operating instructions contained in all the documentation delivered with the appliance.
 - Know the location and proper use of all controls.
 - Keep this manual and all supplied instructions, diagrams, schematics, parts lists, notices, and labels with the appliance if the appliance is sold or moved to another location.
 - Contact Alto-Shaam for additional training if needed.
-

Operator qualifications

Only trained personnel with the following operator qualifications are permitted to use the appliance:

- Have received proper instruction on how to use the appliance.
- Have demonstrated their ability with commercial kitchens and commercial appliances.

The appliance must not be used by:

- Persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision concerning use of the appliance by person responsible for their safety.
 - People impaired by drugs or alcohol.
-

- Children should be supervised to ensure that they do not play with the appliance.
 - Children shall neither clean nor maintain the appliance.
-

Condition of appliance

Only use the appliance when:

- All controls operate correctly.
 - The appliance is installed correctly.
 - The appliance is clean.
 - The appliance labels are legible.
-

Servicing the appliance

- Only trained personnel are permitted to service or repair the appliance. Repairs that are not performed by an authorized service partner or trained technician, or the use of non-factory parts, will void the warranty and relieve Alto-Shaam of all liability.
 - To prevent serious injury, death or property damage, have the appliance inspected and serviced at least every twelve (12) months by an authorized service partner or trained technician.
 - Contact Alto-Shaam for the authorized service partner in your area.
-

Sound power

The A-weighted sound pressure level is below 70 dB(A).


Personal Protective Equipment (PPE)

Wear the following Personal Protective Equipment (PPE) while cleaning the appliance:

- Protective gloves
- Protective clothing
- Eye protection
- Face protection







This page intentionally left blank.








Label Locations








VMC-PHD-006220

LABELS


| <p>1</p> |  <p>WARNING/ADVERTENCIA/AVERTISSEMENT</p> <p>Electric Shock Hazard To reduce the risk of electric shock, do not remove or open cover. No user-serviceable parts inside. Refer servicing to qualified personnel. Qualified personnel: Disconnect power before servicing.</p> <p>Peligro de descarga eléctrica Para reducir el riesgo de descarga eléctrica, no retire ni abra la cubierta. No hay piezas en el interior a la que se les pueda realizar mantenimiento. Derive el mantenimiento a personal calificado. Personal calificado: Desconecte la energía antes de realizar mantenimiento.</p> <p>Danger de décharge électrique Pour réduire le risque de décharge électrique, ne par ouvrir ni retirer le capot. Ne contiennent pas de pièces réparables par l'utilisateur. Confier les réparations à du personnel qualifié. Personnel qualifié : Sectionnez l'alimentation avant toute intervention.</p> <p>LA-38950</p>  | <p>WARNING</p> <p>Electric shock hazard</p> <p>To reduce the risk of electric shock, do not remove or open the cover. No user-serviceable parts inside. Refer servicing to qualified personnel. Qualified personnel: Disconnect power before servicing.</p> | | | | | | | | | | | | | | | |
|------------------------|---|---|--------------|------------------|----------------|-----------|-----------|-----------------------|-----------|-----------|----------------------|-----------|-----------|------------------------|-----------|-----------|---|
| <p>2</p> |  <p>Use ____AWG for supply connections. Use only copper wires suitable for temperatures ≥ 90°C. Do not connect to a circuit operating at more than 150 VAC to ground. For use on individual branch circuits only.</p> <p>Use AWG ____ para las conexiones de suministro. Use solo cables de cobre aptos para temperaturas mayores que 90 °C. No conecte a un circuito que funcione a más de 150 V CA a tierra. Para su uso en circuitos derivados individuales solamente.</p> <p>Utiliser du calibre ____AWG pour les raccordements électriques. Utiliser exclusivement des conducteurs en cuivre qui conviennent à des températures ≥ 90 °C. Ne pas raccorder à un circuit fonctionnant sous plus de 150 VCA par rapport à la terre. Utiliser exclusivement sur des circuits de dérivation propres.</p> <p>AWG 90°C</p> <p>LA-38852</p> | <p>Note: This label is only used on UL-certified appliances that have 120V to ground wiring.</p> <p>Use ____ AWG for supply connections.</p> <p>Use only copper wires suitable for temperature less than or equal to 90°C.</p> <p>Do not connect to a circuit operating at more than 150 VAC to ground.</p> <p>For use on individual branch circuits only.</p> | | | | | | | | | | | | | | | |
| <p>3</p> |  <p>WARNING/ADVERTENCIA/AVERTISSEMENT</p> <p>Fire Hazard For use only on noncombustible surfaces. Maintain the correct clearances to combustibles.</p> <p>Peligro de incendio Solo para uso en superficies no combustibles. Mantenga las distancias correctas de elementos combustibles.</p> <p>Risque d'incendie Utilisation sur des surfaces non combustibles seulement. Maintenir des dégagements corrects par rapport aux matières combustibles.</p> <table border="1"> <thead> <tr> <th></th> <th>Combustibles</th> <th>Non-combustibles</th> </tr> </thead> <tbody> <tr> <td>Top/above/haut</td> <td>2" (51mm)</td> <td>2" (51mm)</td> </tr> <tr> <td>Left/leftierda/gauche</td> <td>2" (51mm)</td> <td>2" (51mm)</td> </tr> <tr> <td>Right/derecho/droite</td> <td>2" (51mm)</td> <td>2" (51mm)</td> </tr> <tr> <td>Rear/posterior/arrière</td> <td>2" (51mm)</td> <td>2" (51mm)</td> </tr> </tbody> </table> <p>LA-38900</p>  <p>LA-38994</p> | | Combustibles | Non-combustibles | Top/above/haut | 2" (51mm) | 2" (51mm) | Left/leftierda/gauche | 2" (51mm) | 2" (51mm) | Right/derecho/droite | 2" (51mm) | 2" (51mm) | Rear/posterior/arrière | 2" (51mm) | 2" (51mm) | <p>WARNING</p> <p>Fire hazard</p> <p>For use only on noncombustible surfaces. Maintain the correct clearances to combustibles.</p> |
| | Combustibles | Non-combustibles | | | | | | | | | | | | | | | |
| Top/above/haut | 2" (51mm) | 2" (51mm) | | | | | | | | | | | | | | | |
| Left/leftierda/gauche | 2" (51mm) | 2" (51mm) | | | | | | | | | | | | | | | |
| Right/derecho/droite | 2" (51mm) | 2" (51mm) | | | | | | | | | | | | | | | |
| Rear/posterior/arrière | 2" (51mm) | 2" (51mm) | | | | | | | | | | | | | | | |
| <p>4</p> |  <p>ALTO-SHAAM.</p> <p>Every Alto-Shaam product is precision calibrated prior to release from the factory to ensure accurate temperature control.</p> <p>CALIBRATION TECHNICIAN _____</p> <p>LA-26378</p> | <p>Every Alto-Shaam product is precision calibrated prior to release from the factory to ensure accurate temperature control.</p> | | | | | | | | | | | | | | | |

| | | |
|----|---|---|
| 5 |  | <p>WARNING Hot surface</p> |
| 6 |  | <p>Made in U.S.A.</p> |
| 7 | <div data-bbox="261 573 727 730"> <p>WARNING / ADVERTENCIA / AVERTISSEMENT</p> <p>Burn hazard. Always load liquids, or foods that can become liquid when heated, at an eye level where they can be seen.</p> <p>Peligro de quemaduras. Siempre coloque líquidos, o alimentos que se puedan volver líquidos cuando se calientan, a nivel de los ojos donde se puedan ver.</p> <p>Risque de brûlure. Toujours charger les liquides, ou les aliments qui deviennent liquides au chauffage, à hauteur des yeux où ils peuvent être vus.</p> <p style="text-align: right;"><small>LA-39123</small></p> </div>  | <p>WARNING Burn hazard</p> <p>Always load liquids, or foods that can become liquid when heated, at an eye level where they can be seen.</p> |
| 8 |  | <p>Security seal</p> |
| 9 | <div data-bbox="261 1087 639 1199"> <p>Check fans Compruebe los ventiladores Vérifiez les ventilateurs</p> <p style="text-align: right;"><small>LA-39033</small></p> </div> <div data-bbox="261 1247 639 1367">  <p style="text-align: right;"><small>LA-39280</small></p> </div> | <p>Check fans</p> |
| 10 |  <p style="text-align: center;"><small>LA-36443-L1</small></p> | <p>Line 1 supply terminal</p> |
| 11 |  <p style="text-align: center;"><small>LA-36443-L2</small></p> | <p>Line 2 supply terminal</p> |

LABELS

| | | |
|----|--|---|
| 12 |  | Line 3 supply terminal |
| 13 |  | Neutral |
| 14 |  | Ground terminal |
| 15 |  | Equipotential terminal |
| 16 |  | Press and release the high limit temperature reset button(s). |

Dimension Drawings



INSTALLATION

How to Receive the Appliance

Responsible parties

When an Alto-Shaam preferred carrier is used, shipping damage is a matter between Alto-Shaam and the carrier. In such cases, contact Alto-Shaam customer service.

When an Alto-Shaam non-preferred carrier is used, shipping damage is a matter between the carrier and the consignee. In such cases, the carrier is assumed to be responsible for the safe delivery of the merchandise, unless negligence can be established on part of the shipper.

Receive the appliance

When receiving the appliance, do the following.

| Step | Action |
|------|---|
| 1. | Inspect the equipment while it is still in the truck or immediately after it is moved to the receiving area. Do not wait until after the equipment is moved to a storage area. |
| 2. | Inspect and count all merchandise received. Do not sign a delivery receipt or a freight bill until you have done so. |
| 3. | Note all damage to packaging and to the equipment on the carrier's receipt. |
| 4. | Request the driver sign the delivery receipt. If the driver refuses to sign, make a note of this refusal on the delivery receipt. |
| 5. | Write the following on the delivery receipt if the driver refuses to allow an inspection: Driver refuses to allow inspection of containers for visible damage. |
| 6. | Contact the carrier immediately upon finding damage, and request an inspection. Follow the carrier's policies and procedures. |

Alto-Shaam policy

It is the policy of Alto-Shaam to assist customers in collecting claims that have been properly filed and actively pursued. Alto-Shaam cannot, however, file damage claims, assume the responsibilities for damage claims, or accept deductions in payment for damage claims.

How to Unpack the Oven


Before you begin

Make sure you have:

- An appropriate lifting device and enough personnel to safely move and position the weight of the oven.
 - VMC-H2/H2H: 213 lb (97 kg)
 - VMC-H3/H3H: 278 lb (126 kg)
 - VMC-H4/H4H: 348 lb (158 kg)
- Cutting tools to remove the packaging.

Unpack the oven

To unpack the oven, do the following.

| Step | Action |
|--|---|
| 1. | Remove the box. Save all packing materials for inspection by the carrier. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>NOTE: Examine the appliance for damage. If the appliance has been damaged, do not use the appliance until it has been inspected by an authorized service provider. Contact your carrier or Alto-Shaam customer service.</p> </div> |
| 2. | Remove the shrink wrap. |
| 3. | Cut the restraining straps. |
| 4. | Remove the tape ① that holds the filters (if equipped). Remove the screws ② that holds the filters (if equipped). |
|  <p style="text-align: right; font-size: small;">VMC-TS-007663</p> | |
| 5. | Remove the foam from each chamber. |
| 6. | Remove the oven from the pallet. |

Result

The oven is now unpacked.

Vector Pre-Installation Checklist

Installation of the oven is to be completed only by an authorized Alto-Shaam service partner.

Place this form with the oven's records.



WARNING: Electric shock and arc flash hazard.
Use caution when measuring line voltage and line current.
Wear Personal Protective Equipment (PPE).

Location Information

| | |
|---|----------------------------------|
| Installation date: | Start up date: |
| Location name: | Location address: |
| Contact name: | |
| Contact phone number: | Number of ovens to be installed: |
| Contact email: | Oven model number(s): |
| IT Administrator name: (if applicable) | Oven serial number(s): |
| Phone number: | Oven rated voltage: |

Pre-Installation Company Information

| | |
|--------------------------|-------------------|
| Company name: | Mailing address: |
| Technician name: | |
| Technician phone number: | Technician email: |
| Date of Site Survey: | |

Clearance

| | Record | Pass | Fail |
|---|----------|------|------|
| Measure door/entry way clearance (smallest dimension) | | | |
| Measure path clearance (smallest dimension) | | | |
| Elevator opening, if applicable (smallest dimension) | | | |
| Elevator interior dimensions, if applicable (HXWXD) | | | |
| Oven Clearance Right side: | | | |
| Rear: | | | |
| Left side: | | | |
| Top: | | | |
| Based on the oven's designated spot in the kitchen, is the oven accessible for service? | Yes / No | | |
| If NO, comment on the issue: | | | |
| Other comments: | | | |

Continued on next page

Continued from previous page

Electrical

| | | | | |
|---|----------|----------|--------|--------|
| Alto-Shaam oven ratings | Breaker: | Voltage: | Phase: | |
| The following fields must be completed by the service technician on site. | | | | |
| What is the measured voltage at the site? | L1-N: | L2-N: | L3-N: | L1-L2: |
| | L2-3: | L1-L3: | Pass | Fail |
| What is the on-site breaker size supplying power to the oven(s)? | Size: | | Pass | Fail |
| Is there a disconnect or junction box within 3' (914mm) of where the oven(s) will be installed? | Pass | Fail | | |
| Comments: | | | | |

Gas-F Series only

| | | | | |
|--|---------|---------|------|------|
| What is the gas type for the oven(s) to be installed? | Natural | Propane | | |
| What is the gas type confirmed at installation site? | Natural | Propane | Pass | Fail |
| Is there a minimum of one 3/4" gas supply line within 3' (914mm) of where the oven(s) will be installed? | Pass | Fail | | |
| On the gas line, is there a 3/4" NPT pipe connection with a shut-off valve within 3' (914mm) of where the oven(s) will be installed? | Pass | Fail | | |
| Comments: | | | | |

Wifi equipped ovens

| | | |
|---|-----|----|
| Is the Wifi system that be used secure, Wifi Protected Access 2 (WPA2)? The Wifi system to be used cannot be Point of Sales Wifi. | Yes | No |
| Have you been provided the Service Set Identifier (SSID) for the system to be used? | Yes | No |
| Have you been provided the pass phrase for the Wifi system to be used? | Yes | No |
| At the final location that the oven will be installed, can you connect to the Wifi system with your phone? | Yes | No |
| At the final location that the oven will be installed, can you connect to Alto-Shaam.com with your phone using the Wifi system? | Yes | No |
| Is site action required? | Yes | No |
| Action required: | | |

Continued on next page

Continued from previous page

Other site information

| | | |
|--|------|------|
| Is there a proper ventilation hood installed above where the oven(s) will be installed? (If required) | Pass | Fail |
| Does the designated location for the oven have a level surface, i.e., no more than 1.5" (38mm) change in elevation from its highest to lowest surface point? | Pass | Fail |
| Is the ambient temperature range of the site 60°F – 110°F° (16°C – 43°C)? | Pass | Fail |
| Is the site 100% ready for oven(s) installation? | Pass | Fail |
| Is site action required? | Pass | Fail |

Action required:

Continued on next page

Continued from previous page

Please provide a copy of this document to an on-site manager.

Service company name:

Service company number:

Model of oven(s) to be installed:

The site is ready for installation of the oven(s); planned install location passes inspection. Once the oven(s) arrive at the site (or the delivery date is certain), please contact the service company listed above to schedule the installation.

The site is NOT ready for installation of the oven(s); planned install location needs the following changes made before installation can proceed:

On-site manager should make the necessary contacts to move forward with these changes as soon as possible. If there are any questions, please contact Alto-Shaam Technical Service Department at 800-558-8744 ext. 6702.
Or, review documentation regarding the equipment www.alto-shaam.com/en/resource-library.

Once the necessary site changes have been made and the oven(s) have arrived (or the delivery date is certain), please contact the service company listed above to schedule the installation.

Technician name and signature:

On-site manager name and signature:

Installation Checklist

Installation of the oven is to be completed only by an authorized Alto-Shaam service partner.

Place this form with the oven's records.



WARNING: Electric shock and arc flash hazard.
Use caution when measuring line voltage and line current.
Wear Personal Protective Equipment (PPE).

| | |
|---|---------------------|
| Installation date: | Start up date: |
| Location name: | Location address: |
| Contact name: | |
| Contact phone number: | Oven model number: |
| Contact email: | Oven serial number: |
| IT Administrator name: (if applicable) | Oven rated voltage: |
| Phone number: | |

| Oven physical condition | Damaged | | Record any damage with details before or after uncrating, location of damage, etc. Take pictures. |
|-------------------------|---------|----|---|
| | Yes | No | |
| Front of oven | | | |
| Left side | | | |
| Back of oven | | | |
| Right side | | | |
| Top and bottom/legs | | | |

| Oven visual inspection (outside) | Yes | No |
|---|-----|----|
| Is all packing material removed from the outside of the oven? | | |
| Is all packing material removed from the inside of the oven? | | |
| Are all of the cooling fan filters installed correctly? | | |
| Are all of the internal grease filters installed correctly? (H Series models only) | | |
| Are all of the jet plates in place and installed correctly? | | |

| Oven visual inspection (internal) | Loose/Damaged | |
|--|---------------|----|
| | Yes | No |
| Check all electrical connections at each terminal block. | | |
| Check all circuit board connections. | | |
| Check all components for loose connections and hardware. | | |
| Check the overall system for any damage from shipping or installation. | | |

Continued on next page

Continued from previous page

| Electrical: | Record | | |
|---|---------------|-----------|-----------|
| Measure the voltage at the wall outlet. | L1 to L2: | L1 to L3: | L2 to L3: |
| Measure the voltage at the oven's main disconnect switch. | L1 to L2: | L1 to L3: | L2 to L3: |
| Measure the voltage at the oven's main terminal block. | L1 to L2: | L1 to L3: | L2 to L3: |
| Measure the AC voltage to the 12 VDC power supply. | | | |
| Measure the DC output from the power supply. | | | |

Turn the oven on. Press and release the high limit temperature reset buttons. Start the preheat cycle for all of the oven chambers.


| Terminals A1 to A2 | Record | F Models | Record |
|---------------------------|---------------|------------------|---------------|
| SSR 1 DC voltage | | SSR 5 DC voltage | |
| SSR 2 DC voltage | | SSR 6 DC voltage | |
| SSR 3 DC voltage | | SSR 7 DC voltage | |
| SSR 4 DC voltage | | SSR 8 DC voltage | |

| Heating elements: | Left side | Right side | |
|--------------------------|------------------|------------------------|---------------|
| | Record | F Models | Record |
| Amperage for chamber 1 | | Amperage for chamber 1 | |
| Amperage for chamber 2 | | Amperage for chamber 2 | |
| Amperage for chamber 3 | | Amperage for chamber 3 | |
| Amperage for chamber 4 | | Amperage for chamber 4 | |

Wifi equipped ovens:

Navigate to the settings screen, touch the network icon.



| On the Your network status screen: | Wireless | | Ethernet |
|---|-----------------|--------|-----------------|
| What is the connection type? | | | |
| What color is the network icon?  | Red | Yellow | Green |
| What is the Internet status? | | | |
| What is the Cloud status? | | | |
| What is the SSID? | | | |
| What is the IP Address? | | | |

How to Install the Oven (60 Hz Cord and Plug Models)

Before you begin

Make sure you have:

- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - VMC-H2/H2H: 213 lb (97 kg)
 - VMC-H3/H3H: 278 lb (126 kg)
 - VMC-H4/H4H: 348 lb (158 kg)

Requirements

- The oven must be installed on a level surface.
- The oven must not be installed in any area where it may be affected by steam, grease, dripping water, high temperature, or any other severely adverse conditions.
- The oven is not intended for built-in installation.

Voltages

| | V | Ph | Hz | A | Breaker* | kW | Plug Configuration |
|--------------------|-----|----|----|----|----------|------|--------------------|
| VMC-H2/ VMC-H2H | 208 | 1 | 60 | 25 | 30 | 5.2 | NEMA 6-30P |
| | 240 | 1 | 60 | 28 | 30 | 6.7 | NEMA 6-30P |
| VMC-H3/ VMC-H3H | 208 | 1 | 60 | 38 | 50 | 7.9 | NEMA 6-50P |
| | 240 | 1 | 60 | 43 | 50 | 10.3 | NEMA 6-50P |
| | 208 | 3 | 60 | 22 | 30 | 7.9 | NEMA 15-30P |
| | 240 | 3 | 60 | 25 | 30 | 10.3 | NEMA 15-30P |
| VMC-H4/ VMC-H4H | 208 | 3 | 60 | 33 | 40 | 10.6 | NEMA 15-50P |
| | 240 | 3 | 60 | 38 | 40 | 13.9 | NEMA 15-50P |

*Electrical connections must meet all applicable federal, state, and local codes.

Continued on next page

Continued from previous page


Position the oven

To position the oven, do the following.

| Step | Action |
|------|--|
| 1. | Make sure that: |
| | <ul style="list-style-type: none"> The location where the oven is being installed is rated to support the weight of the oven; The oven is within five feet (1.5m) of the appropriate electrical outlet; You follow the oven clearance guidelines. |
| |  |
| 2. | Move the oven to the installation location and onto the final resting surface. |

1. **Make sure** that:

- The location where the oven is being installed is rated to support the weight of the oven;
- The oven is within five feet (1.5m) of the appropriate electrical outlet;
- You follow the oven clearance guidelines.



VMC-DIM-007498


2. **Move** the oven to the installation location and onto the final resting surface.

The oven is now correctly positioned.

Level the oven

To level the oven, do the following.

3. **Check** the level of the oven using a spirit (bubble) level. Check front to back and side to side.



VMC-TS-007501

Adjust the legs, if necessary, to achieve levelness.

The oven is now correctly positioned.


Continued on next page

Continued from previous page

Connect power


To connect electric power to the oven, do the following.

4. **Set** the main disconnect switch ① to the OFF position.



VMC-TS-006236


5. **Connect** the plug to the electrical outlet.



VMC-TS-000318

Press reset button(s)

6. **Press and release** the high limit temperature reset button(s) ②.
Remove the tag ③.



VMC-TS-007505

Result

The oven is now installed and ready to be used.

How to Install the Oven (60 Hz Models Without Cords or Plugs)

Before you begin

Make sure you have:

- Appropriate cord and plug. See local codes and regulations.
- Screwdriver (Phillips #2)
- Nut driver (1/4-inch)
- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - VMC-H2/H2H: 213 lb (97 kg)
 - VMC-H3/H3H: 278 lb (126 kg)
 - VMC-H4/H4H: 348 lb (158 kg)

Requirements

- The oven must be installed on a level surface.
- The oven must not be installed in any area where it may be affected by steam, grease, dripping water, high temperature, or any other severely adverse conditions.
- The oven is not intended for built-in installation.

Voltages

| | V | Ph | Hz | A | Breaker* | kW |
|--------------------|-----|----|-------|----|----------|------|
| VMC-H2/ VMC-H2H | 220 | 1 | 50/60 | 25 | 32 | 5.4 |
| | 240 | 1 | 50/60 | 28 | 32 | 6.4 |
| | 380 | 3 | 50/60 | 12 | 16 | 5.4 |
| | 415 | 3 | 50/60 | 13 | 16 | 6.4 |
| VMC-H3/ VMC-H3H | 220 | 1 | 50/60 | 37 | 63 | 8.1 |
| | 240 | 1 | 50/60 | 41 | 63 | 9.6 |
| | 380 | 3 | 50/60 | 12 | 16 | 8.1 |
| | 415 | 3 | 50/60 | 13 | 16 | 9.6 |
| VMC-H4/ VMC-H4H | 380 | 3 | 50/60 | 23 | 32 | 10.8 |
| | 415 | 3 | 50/60 | 25 | 32 | 12.7 |

*Electrical connections must meet all applicable federal, state, and local codes.

Continued on next page


Continued from previous page

Position the oven

To position the oven, do the following.

| Step | Action |
|--|---|
| 1. | <p>Make sure that:</p> <ul style="list-style-type: none"> The location where the oven is being installed is rated to support the weight of the oven, The oven is within five feet of the appropriate electrical outlet, You follow the oven clearance guidelines. |
|  | |
| 2. | <p>Move the oven to the installation location and onto the final resting surface.</p> |
| <p>The oven is now correctly positioned.</p> | |
| <h2>Level the oven</h2> | |
| <p>To level the oven, do the following.</p> | |
| 3. | <p>Check the level of the oven using a spirit (bubble) level. Check front to back and side to side.</p> |
|  | |
| <p>Adjust the legs, if necessary, to achieve levelness.</p> | |


- The location where the oven is being installed is rated to support the weight of the oven,
- The oven is within five feet of the appropriate electrical outlet,
- You follow the oven clearance guidelines.



VMC-DIM-007498

The oven is now correctly positioned.

To level the oven, do the following.



VMC-TS-007501

Adjust the legs, if necessary, to achieve levelness.

Continued on next page

Continued from previous page


Connect the wiring

To connect the wiring, do the following.

4. **Remove** the pivot screws. **Remove** the top cover ①.




WARNING: Electric shock hazard.
Make sure the supply cord is not connected to a power supply.




VMC-TS-007943

5. **Remove** the bottom 3 screws ② from the mounting bracket.
Remove the main disconnect switch ③ from the mounting bracket.



VMC-TS-001815

6. **Install** the cord ④ through the cord grip ⑤ and install to oven.
Install the lock nut onto the cord grip.




VMC-TS-007946

Continued on next page

Continued from previous page


7. **Connect** the supply cord to the appropriate terminals (L1, L2, L3, etc.) in accordance with local codes and regulations.

VMC-H2 VMC-H2H
VMC-H3 VMC-H3H



VMC-TS-001821

VMC-H3 VMC-H3H
VMC-H4 VMC-H4H




VMC-TS-001825

Continued on next page

Continued from previous page


8. **Install** the ground wire ⑥.
Adjust the cord length.
Tighten the cord grip sealing nut onto the supply cord.



VMC-TS-001829

9. **Re-install** the main disconnect switch.
10. **Re-install** the mounting bracket.
11. **Re-install** the top cover.
12. **Press and release** the high limit temperature reset button(s) ⑦.
Remove the tag ⑧.

Press reset button(s)



VMC-TS-007949

Result

The oven is now installed.

How to Install the Oven (50 Hz Models Without Cords or Plugs)

Before you begin

Make sure you have:

- Appropriate cord and plug, minimum oil resistant HO7RN-F. See local codes and regulations.
- Screwdriver (Phillips #2)
- Nut driver (1/4-inch)
- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - VMC-H2/H2H: 213 lb (97 kg)
 - VMC-H3/H3H: 278 lb (126 kg)
 - VMC-H4/H4H: 348 lb (158 kg)

Requirements

- The oven must be installed on a level surface.
- The oven must not be installed in any area where it may be affected by steam, grease, dripping water, high temperature, or any other severely adverse conditions.
- If required by local codes, use Type F RCD.
- The oven is not intended for built-in installation.

Voltages

| | V | Ph | Hz | A | Breaker* | kW | Wire Size (mm) |
|---------------------|-----|----|----|----|----------|------|----------------|
| VMC-H2H 220-240V | 220 | 1 | 50 | 25 | 32 | 5.4 | 4 |
| | 240 | 1 | 50 | 28 | 32 | 6.4 | 4 |
| 380-415V | 380 | 3 | 50 | 12 | 16 | 5.4 | 1.5 |
| | 415 | 3 | 50 | 13 | 16 | 6.4 | 1.5 |
| VMC-H3H 220-240V | 220 | 1 | 50 | 37 | 63 | 8.1 | 10 |
| | 240 | 1 | 50 | 41 | 63 | 9.6 | 10 |
| 380-415V | 380 | 3 | 50 | 12 | 16 | 8.1 | 1.5 |
| | 415 | 3 | 50 | 13 | 16 | 9.6 | 1.5 |
| VMC-H4H 380-415V | 380 | 3 | 50 | 23 | 32 | 10.8 | 4 |
| | 415 | 3 | 50 | 25 | 32 | 12.7 | 4 |

*Electrical connections must meet all applicable federal, state, and local codes.


Wire sizes

60335-1 IEC:2010

| Rated current of appliance A | Nominal cross-sectional area mm ² |
|---------------------------------|---|
| >0.2 - ≤3 | 0.5 |
| >3 - ≤0 | 0.75 |
| >6 - ≤10 | 1.0 |
| >10 - ≤16 | 1.5 |
| >16 - ≤25 | 2.5 |
| >25 - ≤32 | 4 |
| >32 - ≤40 | 6 |
| >40 - ≤63 | 10 |

Position the oven

To position the oven, do the following.

| Step | Action |
|------|---|
| 1. | <p>Make sure that:</p> <ul style="list-style-type: none"> ■ The location where the oven is being installed is rated to support the weight of the oven, ■ The oven is within five feet of the appropriate electrical outlet, ■ You follow the oven clearance guidelines. |
| |  <p style="text-align: right; font-size: small;">VMC-DIM-007498</p> |
| 2. | <p>Move the oven to the installation location and onto the final resting surface.</p> |

The oven is now correctly positioned.


Continued on next page

Continued from previous page

Level the oven

To level the oven, do the following.

3. **Check** the level of the oven using a spirit (bubble) level. Check front to back and side to side.



VMC-TS-007501

Adjust the legs, if necessary, to achieve levelness.

The oven is now level.

Connect the wiring


To connect the wiring, do the following.

4. **Remove** the top cover ①.



WARNING: Electric shock hazard.

Make sure the supply cord is not connected to a power supply.




VMC-TS-007943


Continued on next page

Continued from previous page


5. **Remove** the bottom 3 screws ② from the mounting bracket.
Remove the main disconnect switch ③ from the mounting bracket.



6. **Install** the cord ④ through the cord grip ⑤.
Install the cord and cord grip into the oven.
Install the lock nut onto the cord grip.



7. **Connect** the supply cord to the appropriate terminals (L1, L2, L3, etc.) in accordance with local codes and regulations.





Continued on next page

Continued from previous page

8. **Install** the ground wire ⑥.

Leave an extra loop ⑦ so that current-carrying conductors become taut before the ground wire if the cord is accidentally pulled. Follow applicable regulations.

Tighten the cord grip sealing nut onto the supply cord.



NOTE: The equipotential-bonding terminal is located at the bottom rear of the oven.


9. **Re-install** the main disconnect switch.
10. **Re-install** the mounting bracket.
11. **Re-install** the top cover.

Continued on next page

Continued from previous page

Press reset button(s)

12. **Press and release** the high limit temperature reset button(s) ⑧.
Remove the tag ⑨.



Result

The oven is now installed.

How to Install the Oven on a Stand

Before you begin

Make sure you have:


- The appropriate stand for your oven
- Regulation UL 197, 91.8
- An appropriate lifting device, and enough personnel, to safely move and position the weight of the oven.
 - VMC-H2/H2H: 213 lb (97 kg)
 - VMC-H3/H3H: 278 lb (126 kg)
 - VMC-H4/H4H: 348 lb (158 kg)

Procedure

To install the ovens, do the following.


| Step | Action |
|------|--------|
|------|--------|

- | | |
|----|---|
| 1. | Remove the feet, or the casters and mounting plates ①. |
|----|---|



- | | |
|----|---|
| 2. | Lift the oven and set it on the stand. |
|----|---|

- | | |
|----|---|
| 3. | Connect the oven to the stand with the supplied fasteners ②. |
|----|---|




Continued on next page

Continued from previous page

Install wheels on lower oven

To install the casters on the lower oven, do the following.


4. **Attach** each caster with fasteners as shown.



5. **Level** the unit as necessary. To do so, screw the wheel up or down until the unit is level. Tighten the jam nut (3).


Slide a piece of the tubing (4) over the exposed screws if more than 1/4-inch of thread is exposed.

Attach wire tie (5) around the tubing to hold it in place.



Install the tether

6. **Install** the tether to the lower oven. Install the tether so that no stress is transmitted to the electrical cord when the oven moves.



Result

The oven is now installed to the stand.

How to View and Set up Network Connections

Before you begin

- The facility must have WIFI.
- Do not connect to a guest network.

Procedure


To set up WIFI, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006259</p> |
| 2. | <p>Touch the settings icon ②. The general settings screen displays.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006262</p> |
| 3. | <p>Touch the WIFI icon ③. The Network Status screen displays.</p>  <p style="text-align: right; font-size: small;">AS-TS-009330</p> |

Continued on next page

Continued from previous page

4. **Scroll** to “Connection settings”. **Touch** the SSID > icon ④.




The available networks will show on the screen. The color of the network icon indicates the strength of the signal for each network.


Green = strong

Red = weak

If the network to be used is not displayed, continue with step 5.



5. If the network is not available, **touch** the “Add network” icon ⑤.



Enter the SSID using the keypad. Then, **touch** the arrow key.

Enter the security type. Then, **touch** the check mark.

Enter the password using the keypad. Then, **touch** the arrow key.

Touch the check mark when finished.

Result

The procedure is now complete.

This page intentionally left blank.

How to Turn On and Turn Off the Oven


Before you begin

The oven must be connected to electric power.

Turning on the oven

To turn on the oven, do the following.

| Step | Action |
|--|--|
| 1. | <p>Set the main disconnect switch ① to the ON position.</p> <p>Touch the ON/OFF button ②.</p> <div data-bbox="597 619 1339 724" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>i NOTE: The main disconnect switch is meant to be used during cleaning or service operations. For every day operation, it may be left in the ON position.</p> </div> <div data-bbox="544 745 1388 1071" style="display: flex; justify-content: space-around;">   </div> <p style="text-align: right; font-size: small;">VMC-TS-006253</p> |
| <p>The oven is now on.</p> | |
| <h2>Turning off the oven</h2> <p>To turn off the oven, do the following.</p> | |
| 2. | <p>Touch and hold the ON/OFF button until the Shut down options screen displays.</p> <p>Touch Shut down to turn off the oven.</p> <p>The oven activates the blowers for the cool down process. The oven deactivates the blowers when the cool down process is complete.</p> |
| <p>The oven is now off.</p> | |



How to Preheat the Oven



Before you begin

Make sure:

- The oven is turned on.
- The oven door is closed.

Procedure


To preheat the oven, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006262</p> |
| 3. | <p>Scroll to the Temperature Settings.</p> <p>Touch the preheat chamber setting ③. The existing temperature displays. Enter the preheat temperature using the number pad. Touch the check mark.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006265</p> |


Continued on next page

Continued from previous page

4. **Touch** the check mark ④ to save the preheat temperature settings.
Touch the manual cook icon ⑤ to return to the manual cook screen.



5. **Touch** the preheat icon ⑥. The preheat all chambers confirmation screen displays.
Touch "Preheat" ⑦. All chambers start to preheat to their preset temperatures.



Screen loading bars

Red loading bars indicate each chamber's progress towards reaching its set temperature.

Touch the cancel icon ⑧ to cancel the preheating process before the individual chamber reaches its preset preheat temperature. Each chamber must be canceled individually.



Result

The oven is preheating. When the preheat process is complete, the screen displays Ready for each chamber.

How to Cook with Programmed Recipes



Before you begin

Make sure:

- The oven is preheated.
- Your food is prepared and ready to cook.


Procedure

To cook using a programmed recipe, do the following.



| Step | Action |
|------|--|
| 1. | <p>Touch the recipes icon ①. The browse recipes screen displays.</p>  |
| 2. | <p>Navigate to the recipe.</p> <p>Touch the recipe ②.</p> <p>Touch the start icon ③.</p>  |
| 3. | <p>Select the available chamber(s) ④.</p> <p>Open the door and load the food into the chamber. Close the door.</p> <p>Touch the start icon ⑤.</p>  |

During the cooking process

The cooking status screen displays the details on the current cook setting.




During the cooking process:

| Action | Result |
|---|--|
| Touch the hand icon  when action is required... | to continue the cooking process. |
| Touch the chamber... | to show the recipe details. |
| Touch and hold the chef's hat next to the cooking parameters...  | to show the current chamber temperature. |
| Touch "X"... | to cancel the cooking process. |

Result

At the end of the cooking process, the oven sounds an alert and both the chamber light and door handle light flash. Remove the cooked food.

 **NOTE:** Be sure to remove the cooked food after pressing "Continue". By pressing "Continue" the oven will revert back to the preheat temperature. If left inside the oven, the food will continue to cook.



How to Cook in Manual Mode

Before you begin

Be sure your food is prepared and ready to cook.

Background

This procedure consists of:


- Setting the preheating stage;
- setting the food loading action;
- and setting the cooking stage parameters (temperature, time, and fan speed).

Procedure

To cook in manual mode, do the following.


| Step | Action |
|------|--------|
|------|--------|

1. **Touch** the manual cook icon ①. The available chambers are displayed.



VMC-TS-008092

2. **Touch** any available chamber ②.
Touch "Add Stage" ③ to add the preheat stage.



VMC-TS-008095



NOTE:

Touching "Add Stage" ③ adds a cooking stage to the recipe. A stage is a set of cooking parameters: cooking temperature, cooking time, and fan speed.

Touching "Add Action" ④ adds an action step to the recipe. An action adds manual tasks to be completed during the recipe such as loading the food or adding an ingredient.

Continued on next page

Continued from previous page

3. **Touch** the temperature regulation icon ⑤. The oven may need to warm up or cool down to reach your cooking temperature.

Enter a preheat temperature using the key pad. **Touch** the check mark.



4. Now set the cooking parameters. **Touch** the cooking temperature ⑥. **Enter** the cooking temperature using the key pad.

Touch the cooking time ⑦. Enter the cooking time using the key pad.

Slide the slider ⑧ to set the fan speed.



5. **Touch** the start icon ⑨. The preheat process starts.



At the end of the preheat stage, the oven sounds an alert, and both the chamber light and the door handle light flash.

Continued on next page

Continued from previous page

6. **Load** the food into the appropriate chamber. **Touch** the action hand **10**. The cooking stage timer starts to count down.



At the end of the cooking stage, the oven sounds an alert, and the chamber light and door handle light flash.

7. **Open** the door and remove the hot food.

NOTE: Be sure to remove the cooked food after pressing "Continue". By pressing "Continue" the oven will revert back to the preheat temperature. If left inside the oven, the food will continue to cook.



Result

The food is now cooked.

How to Cool Down the Oven


Procedure

To cool down the oven, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the manual cook icon ①.</p>  <p>VMC-TS-008263</p> |
| 2. | <p>Touch the cool down icon ②. The cool down all chambers screen displays.</p> <p>Touch "Cool down" ③. Open the door.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <p>NOTE: The oven activates the blowers for the cool down process. The oven deactivates the blowers when the cool down process is complete.</p> </div>  <p>VMC-TS-008254</p> |

Cooling down progress bars

Above each chamber on the screen, blue progress bars indicate each chamber's progress towards reaching its cool down temperature.



Result

The oven is now cooled down.

How to Create a Recipe





Background

Creating a recipe consists of:

- Setting the cooking stage(s) parameters (temperature, time, and fan speed);
- setting an action step if desired such as adding an ingredient;
- naming the recipe;
- adding a description to the recipe;
- adding a photo to the recipe;
- and adding the recipe to a category.

Procedure

To create a recipe, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the recipes icon ①. The browse recipes screen displays.</p>   <p style="text-align: right;">VMC-TS-006641</p> |
| 2. | <p>Touch the plus icon ②.</p> <p>Touch "Add Stage" ③ to add a cooking stage to the recipe.</p>   <p style="text-align: right;">VMC-TS-009388</p> |

Continued on next page

Continued from previous page

3. Set the cooking parameters. **Touch** the cooking temperature ⑥. Enter the cooking temperature using the key pad. **Touch** the check mark.
Touch the cooking time ⑦. Enter the cooking time using the key pad.
Touch the check mark.
Slide the slider ⑧ to set the fan speed.
Touch the forward arrow icon ④ when finished.




4. **Touch** the plus icon to add an additional stage or action, if needed.
5. **Touch** the forward arrow icon ⑤. The recipe name screen displays.




Continued on next page

Continued from previous page

6. **Enter** the recipe name. **Touch** the forward arrow icon ⑨. The recipe description screen displays.




7. **Enter** the recipe description. **Touch** the forward arrow icon ⑩. The recipe category screen displays.



8. **Select** the recipe category. A check mark displays on the selected recipe category.

Touch the check mark ⑪. The select cover photo screen displays.




Continued on next page

Continued from previous page


9. **Select** the cover photo for the recipe. A check mark displays on the selected photo.

Touch the check mark ⑫. The add photos screen displays.



10. **Select** additional photos for the recipe, if needed. A check mark displays on any selected photos.

Touch the check mark ⑬ when finished to save the recipe.




Result

A new recipe has been created.


How to Modify, Duplicate, or Delete a Recipe

Procedure


To modify, duplicate, or delete a recipe, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the recipes icon ①. The browse recipes screen displays.</p>  |

Modifying

| | |
|----|---|
| 2. | <p>To modify a recipe, Touch the recipe settings icon ② of the desired recipe.</p>  |
|----|---|

Touch “Modify recipe”. The first stage of the recipe displays. There will be a screen for each stage. Scroll to the stage you want to modify.

| | |
|--|--|
| |  |
| | <p>Touch the time or temperature space then modify the value using the key pad. Slide the slider to change the fan speed. Touch the forward arrow icon when finished.</p> <p>Touch the trash icon to delete the stage, if desired.</p> |

Continued on next page

Continued from previous page


3. **Touch** the forward arrow icon (5). The recipe name screen displays.



Step through the remaining screens using the forward arrow icon. You will be given the opportunity to change the description and any photos you have included in the recipe. When you get back to the **browse recipes** screen, the changes will be saved.

Duplicating

4. To duplicate a recipe, **Touch** the recipe settings icon (2) of the desired recipe.



Touch "Duplicate recipe" to copy it.

5. Step through the remaining screens using the forward arrow icon. When you get to the naming screen, enter a new name using the keypad.




Step through the remaining screens using the forward arrow icon. Change the parameters of the recipe as desired. When you get back to the **browse recipes** screen, the changes will be saved and the recipe will be visible on the display.

Continued on next page

Continued from previous page


Deleting

6. To delete a recipe, **Touch** the recipe settings icon ② of the desired recipe.



Touch "Remove recipe" to delete it.

Touch "Delete" to confirm that you want to delete the recipe.



Result

The procedure is now complete.




How to Load Recipes from a USB Drive

Before you begin

You will need a USB drive loaded with recipes.

Procedure


To load recipes from the USB drive to the oven, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Plug the USB drive ③ into the port.</p>  <p>VMC-TS-007852</p> |

Continued on next page

Continued from previous page

4. **Scroll** to System Backup & Update.
Touch the Upload recipes from USB ④ setting.



Loading the recipes

The oven loads the recipe file. When the process is complete, the Recipes uploaded screen displays. **Touch** the check mark to return to the settings screen. **Remove** the USB drive.



Result

The recipes are now loaded.




How to Save Recipes to a USB Drive

Before you begin

You will need a USB drive.

Procedure


To download recipes from the oven to a USB drive, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Plug the USB drive ③ into the port.</p>  <p>VMC-TS-007852</p> |

Continued on next page

Continued from previous page

4. **Scroll** to System Backup & Update.
Touch the Download recipes to USB ④ setting.



Loading the recipes

The oven downloads the recipes onto the USB drive. When the process is complete, the Recipes uploaded screen displays. **Touch** the check mark to return to the settings screen. **Remove** the USB drive.



Result

The recipes are now saved to the USB drive.




How to Update Software with a USB Drive

Before you begin

- The chambers should be off (not preheated).
- You will need a USB drive with the updated software.
- Do not remove the USB drive during the update process.

Procedure

To update the software, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Plug the USB drive ③ into the port.</p>  <p>VMC-TS-007852</p> |

Continued on next page

Continued from previous page

4. **Scroll** to System Backup & Update.

Touch the Update system software ④ setting.




Touch Control Board (CB) to update the control board. The oven loads the selected software. The oven verifies the file and then updates the CB.

NOTICE Do not remove the USB drive during the update process.

Touch Front End to update the user interface software. The oven loads the selected software.

Touch Back End to update the supporting software between the control board (CB) and interface board (IB). The oven loads the selected software.

5. **Touch** the check mark when the update is complete to restart the oven.



6. **Remove** the USB drive.



Result

The software has now been updated.

How to Change the Home Screen

Procedure


To change the home screen, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Touch the Home Screen setting ③. The select home screen displays.</p>  <p>VMC-TS-008216</p> |

Continued on next page

Continued from previous page

4. **Select** your desired home screen from the list. **Touch** the check mark ④.
Touch the check mark ⑤ to save the home screen setting.






Result

The home screen has now been changed.

How to Change the Temperature Scale

Procedure


To change the temperature scale from °F to °C and vice versa, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Scroll to the Temperature Settings.</p> <p>Touch the Temperature Units setting ③. The select temperature units screen displays.</p>  <p>VMC-TS-008230</p> |

Continued on next page

Continued from previous page

4. **Select** your desired temperature scale. **Touch** the check mark ④.
Touch the check mark ⑤ to save the temperature scale setting.



Result

The temperature scale has now been changed.

How to Enable the Handle Light

Procedure

To enable the handle light, do the following.

| Step | Action |
|------|--|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p>VMC-TS-006259</p> |
| 2. | <p>Touch the Settings icon ②. The general settings screen displays.</p>  <p>VMC-TS-006262</p> |
| 3. | <p>Scroll to the Handle light setting.</p> <p>Touch the Handle light button ③. Touch the check mark ④. The handle light is now enabled.</p> <p>Repeat the process to disable the handle light.</p>  <p>VMC-TS-008248</p> |

Result

The handle light is now enabled.

How to View Oven Information

Background

This procedure is to be done through the touchscreen on the Deluxe control, not through the ChefLinc™ oven management system.

The oven information screen shows the system info, serial number, network status, connection settings, and cleaning timer.

Procedure

To view oven information, do the following.

| Step | Action |
|------|---|
| 1. | <p>Touch the menu icon ①. The menu screen displays.</p>  <p style="text-align: right; font-size: small;">VMC-TS-006259</p> |
| 2. | <p>Touch the Info page icon ②. The oven information screen displays.</p> <p>Scroll to view the oven model, serial number, system software, network status, and cleaning timer.</p>  <p style="text-align: right; font-size: small;">VMC-TS-008242</p> |

Result

The oven's information has been viewed.

How to Download HACCP Data

Before you begin

You will need a USB drive.

Background


HACCP data provides automated record keeping, set-point validation, recipes used, dates and times. The data is stored until the information is downloaded. Once downloaded, the information is removed from the oven's memory. Best practice would be to download the information every 30 days to a USB drive. The file format is plain text file (.csv). The file can be viewed in Microsoft® Excel.

Procedure


To download HACCP data, do the following.

Step Action


1. **Touch** the menu icon ①. The menu screen displays.



2. **Touch** the HACCP data icon ②. The HACCP data screen displays.




3. **Plug** the USB drive ③ into the port.



Continued on next page


Continued from previous page

4. **Touch** the download icon ④.



Loading the data

The oven downloads the data onto the USB drive. When the process is complete, the download successful screen displays. **Touch** the check mark to return to the menu screen. **Remove** the USB drive.



Result

The HACCP data has now been downloaded.

Maintenance Schedule

Requirements

- See topic *How to Clean the Oven*.
- Make sure the oven is cooled down and off—inside of chamber 140°F (60°C) or less.

Daily

For daily maintenance, do the following.

- **Remove** any spills with disposable paper wipes or a damp cloth.
- **Wipe** the outside of the oven with a damp cloth.
- **Check** the screen for cracking or peeling. Contact Technical Service if needed.

Weekly

For weekly maintenance, do the following.

- **Clean** the entire oven. **Make sure** to use a non-abrasive nylon scrub pad.
- Do not spray the cleaner directly into the fan openings located in the rear of the oven.

Monthly

For monthly maintenance, do the following.

- **Inspect** and clean the cooling fan filters.
- **Inspect** and clean the chamber filters (if equipped).

Yearly

For yearly maintenance, do the following.



NOTE: Must be performed by a qualified professional.

- **Check and tighten** all wire connections.
- **Inspect** the heater flange area for grease leakage.
- **Inspect** the motor flange area for grease leakage.
- **Check and tighten** all display, interface and control board connections.
- **Check and tighten** the door hinges.
- **Inspect** the inner and outer door window panes for cracking or chipping.
- **Test** each chamber fan for correct operation.
- **Test** each chamber heater for correct operation.
- **Test** the chamber lights.
- **Record** the software versions and update if necessary.
- **Inspect** the door gaskets for correct shape and seal.
- **Record** the amp draw of all elements on the service screen individually.
- **Record** the incoming supply line voltage.

How to Clean the Oven

Before you begin



WARNING: Electric shock hazard.
Set the main disconnect switch to the OFF position to remove electric power from the appliance.



CAUTION: Burn hazard.
Allow the oven, utensils, and racks to cool before cleaning.



CAUTION: Corrosive materials hazard.
Wear eye protection and hand protection when cleaning.

NOTICE

Using improper cleaning procedures will damage the catalyst and void the warranty.
Only use spray cleaner when the electric power is completely removed from the oven.
Do not spray water or cleaning solution on the catalyst.
Do not spray cleaner into the oven while the recirculation blower is running.
Do not use steel pads, wire brushes, or scrapers when cleaning.

Daily cleaning procedure

To clean the oven daily, do the following.


| Step | Action |
|------|---|
| 1. | Make sure the oven is turned off and cool—chambers are less than 140°F (60°C). |
| 2. | Remove any spills with disposable paper wipes or a damp cloth. |
| 3. | Wipe the outside of the oven with a damp cloth. |
| 4. | Wipe the outside of the oven with a stainless steel cleaner. |

Continued on next page

Continued from previous page

Weekly cleaning procedure

To clean the oven weekly, do the following.

| Step | Action |
|------|--|
| 1. | <p>Set the main disconnect switch ① to the OFF position. Make sure the oven is cool—chambers are less than 140°F (60°C).</p>  |
| 2. | <p>Spray the exterior areas of the oven with stainless steel polish.</p> <div style="border: 1px solid blue; padding: 5px; margin-top: 10px;"> <p>NOTICE Use only non-caustic cleaners. Do not spray directly into the fan openings on the rear of the oven. Do not use cleaners that contain sodium hydroxide (lye) or phosphorus.</p> </div> |
| 3. | Wipe the exterior areas of the oven with a non-abrasive nylon scrub pad. |
| 4. | Spray the interior areas of the oven with EcoLab Greaselift™ or Chemco Dirt Buster III™ oven cleaner. Let the cleaner work for 3-5 minutes. |
| 5. | Wipe the interior of the oven with a non-abrasive nylon scrub pad. |
| 6. | Clean each side of the window pane with an all-purpose cleaner. |
| 7. | Set the main disconnect switch ① to the ON position when complete. |


Continued on next page

Continued from previous page

Monthly cleaning procedure

To clean the oven monthly, do the following.

| Step | Action |
|---|---|
| 1. | Set the main disconnect switch to the OFF position. Make sure the oven is cool—chambers are less than 140°F (60°C). |
| 2. | Remove the cooking racks ① and jet plates ②. <div data-bbox="662 531 753 615" data-label="Image"> </div> CAUTION: Personal injury hazard. Use hand protection when handling the jet plates. |
| <div data-bbox="587 640 1432 1283" data-label="Image"> </div> | |
| 3. | Separate the jet plates. Flexing the jet plates outward can aid in separating the jet plates. |
| 4. | Spray the jet plates with EcoLab Greaselift™ or Chemco Dirt Buster III™ ③ oven cleaner. Let the cleaner work for 3–5 minutes. Follow safety instructions on cleaner bottle. |
| 5. | Scrub the jet plates with a non-abrasive nylon scrub pad. Rinse the jet plates with water. |
| 6. | Spray a towel with EcoLab Greaselift™ or Chemco Dirt Buster III™ then wipe the inside of the oven. Remove any residue with a water-soaked towel. |
| 7. | Clean the door glass ④ with Windex® or equivalent glass cleaner. |



VMC-TS-006244

Continued on next page


Continued from previous page

8. **Re-install** the jet plates and cooking racks.

i **NOTE:** Make sure the jet plates are installed correctly. The nozzles on the jet plates should be pointing towards the food.

**Cleaning the filters
(if equipped)**

9. **Remove** the filters **5**.



10. **Spray** the filters with a mild cleaner and rinse with hot water.

i **NOTE:** Replace the filters at least once a year.

11. **Re-install** the filters.

12. **Set** the main disconnect switch to the ON position when complete.

Result

The oven is now clean.

This page intentionally left blank.

Error Codes

| Code | Description | Parameters that trigger the error | Possible Cause(s) |
|------|--|---|---|
| 3 | Motor error | No cavity motor rotation detected for greater than 30 seconds. | <ol style="list-style-type: none"> 1. Connection between Variable Frequency Drive (VFD) and control board 2. Connection between fan motor and VFD 3. Fan motor 4. VFD 5. Control board |
| 10 | Sensor short | Short circuit detected on sensor wires. | <ol style="list-style-type: none"> 1. Sensor connection 2. Sensor 3. Control board |
| 11 | Sensor open | Cavity air sensor reading > 650°F (343°C). | <ol style="list-style-type: none"> 1. Sensor connection 2. Sensor 3. Control board |
| 31 | Electronics over temperature | Control board temperature exceeds 158°F (70°C) and/or interface board temperature exceeds 184°F (84°C). | <ol style="list-style-type: none"> 1. Cooling fan filters blocked or dirty 2. Cooling fan not operating 3. Installation clearance requirements not met |
| 94 | Interface Board - Control Board communication error | No signal transfer for more than 5 seconds between the interface board and the control board. | <ol style="list-style-type: none"> 1. Connection of modbus cable 2. Modbus cable 3. Control board 4. Interface board |
| 108 | Bi-metal thermostat open | Open circuit detected across bi-metal switch. | <ol style="list-style-type: none"> 1. Cooling fan filters blocked or dirty 2. Cooling fan not operating 3. Connection between bi-metal switch and control board 4. Installation clearance requirements not met 5. Bi-metal switch |
| 109 | High limit error Note: Contact an authorized Alto-Shaam service partner. | Open circuit detected across high limit switch. | <ol style="list-style-type: none"> 1. Jet plate(s) improperly installed 2. Cavity fan not operating 3. Optional grease filters blocked with debris 4. Heat relay(s) stuck closed 5. Connection between high limit switch and control board 6. High limit switch |


What to do if the Fan Indicator Light Illuminates

Procedure

If the fan indicator light ① illuminates, do the following.

| Step | Action |
|--|--|
| 1. | <p>Turn off the oven and allow it to cool. Remove the filters ②.</p>  |
| 2. | Clean the filters in a dishwasher. |
| 3. | Re-install the filters. |
| 4. | Resume operation of the oven. |
| <p>NOTE: If the fan indicator light remains on, the appliance is malfunctioning. Disconnect the appliance from the power supply and have it serviced by a qualified technician.</p> | |

1. **Turn off** the oven and allow it to cool.
Remove the filters ②.



2. **Clean** the filters in a dishwasher.
3. **Re-install** the filters.
4. **Resume** operation of the oven.

NOTE: If the fan indicator light remains on, the appliance is malfunctioning. Disconnect the appliance from the power supply and have it serviced by a qualified technician.



Result

The procedure is now complete.

What to do if the High Limit Screen Displays

Procedure


If the high limit screen displays, do the following.

| Step | Action |
|------|--|
| 1. | <p>Press and release the high limit temperature reset button(s) ①.</p> <div style="display: flex; align-items: center;">   </div> <p style="text-align: right; font-size: small;">VMC-TS-007607</p> |
| 2. | <p>Resume operation of the oven.</p> <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> <p>NOTE: If the high limit screen continues to display, the appliance is malfunctioning. Turn off the appliance and have the oven serviced by a qualified technician.</p> </div> |


Result

The procedure is now complete.


Cheflinc.alto-shaam.com is not Available on your Device




Cannot Connect to cheflinc.alto-shaam.com



The Oven is not Displayed on the Dashboard



Unable to Assign Recipes from the Dashboard to Ovens in the Field



This page intentionally left blank.

Notifications

FCC ID: N6C-SDPAC

IC ID: 4908A-SDPAC

NOTICE

Federal Communication Interference Statement (United States only)

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

**Canadian Department of Communications Industry Canada Notice
(Canada only)**

This Class B digital apparatus complies with Canadian ICES-003.

FCC Rules, Part 15 / Industry Canada

This device complies with Part 15 of FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of this device.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from a person's body.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

For product available in the USA/Canada market, only channels 1–11 can be operated. Selection of other channels is not possible. If this device is to be operated in the 5.15~5.25GHz frequency range, it is restricted to indoor environments only.

Antenna: Proprietary

Antenna gain information: Embedded Antenna: 3.25dBi (2.4 GHz), 5.0dBi (5 GHz)

Frequency Tolerance: +/-20ppm

WARNING

The FCC / The Industry Canada regulations provide that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

General Specifications

| | |
|----------------------------------|---|
| Chipset: | QCA9377-3, (Qualcomm Atheros) |
| Host Interface: | Wifi: SDIO v3.0; BT: High Speed UART |
| Operating Voltage: | 3.30 VDC +/- 5% |
| Operating Temperature: | -20 to +70 degrees C |
| Dimensions: | 18.0 x 13.0 x 2.2 mm (L x W x D) |
| Connector Type: | 52-pin proprietary |
| Radio Specifications: | 802.11b/g/n: 2.412–2.484 GHz; 802.11a/n: 5.18–5.825 GHz BT: 2.402–2.480 GHz |
| Link Rates (1 stream): | IEEE 802.11b: 1–11 Mbps IEEE 802.11g: 6–54 Mbps IEEE 802.11a: 6–54 Mbps IEEE 802.11n HT20: 6.5–65.0 Mbps IEEE 802.11n HT40: 13.5–135.0 Mbps IEEE 802.11ac VHT20: 6.5–78.0 Mbps IEEE 802.11ac VHT40: 13.5–180.0 Mbps IEEE 802.11ac VHT80: 29.3–390.0 Mbps |
| Modulation Modes: | OFDM (256QAM, 64QAM, 16QAM, QPSK, BPSK), DSSS (CCK, DQPSK, DBPSK), GFSK (1Mbps), $\pi/4$ DQPSK (2Mbps), 8DQPSK (3Mbps) |
| Hardware Encryption: | WEP, WPA/WPA2 (TKIP/AES-CCMP), WAPI |
| Quality of Service (QoS): | WMM, WMM-PS, 802.11e |

This page intentionally left blank.

Warranty

Introduction

Alto-Shaam, Inc. warrants to the original purchaser only, that any original part found to be defective in material or workmanship will be replaced with a new or rebuilt part at Alto-Shaam's option, subject to provisions hereinafter stated.

Warranty Period

The original parts warranty period is as follows:

- For all other original parts, one (1) year from the date of installation of appliance or fifteen (15) months from the shipping date, whichever occurs first.
- The labor warranty period is one (1) year from the date of installation or fifteen (15) months from the shipping date, whichever occurs first.
- Alto-Shaam will bear normal labor charges performed during standard business hours, excluding overtime, holiday rates or any additional fees.
- For the refrigeration compressor, if installed, the warranty period is five (5) years from the date of original installation of the appliance.
- For heating elements on Halo Heat® Cook and Hold ovens, the warranty period is for as long as the original owner owns the oven. This warranty period applies to units sold after 2/1/2009 and excludes holding-only ovens.
- To be valid, a warranty claim must be asserted during the applicable warranty period. This warranty is not transferable.

Exclusions

This warranty does not apply to:

- Calibration.
- Replacement of light bulbs, rubber gaskets, grease filters, air filters, racks, jet plates, and/or the replacement of glass due to damage of any kind.
- Equipment damage caused by accident, shipping, improper installation or alteration.
- Equipment used under conditions of abuse, misuse, carelessness or abnormal conditions, including but not limited to, equipment subjected to harsh or inappropriate chemicals, including but not limited to, compounds containing chloride or quaternary salts, poor water quality, or equipment with missing or altered serial numbers.
- Equipment damage caused by use of any cleaning agents other than those recommended by Alto-Shaam, including but not limited to damage due to chlorine or other harmful chemicals.
- Any losses or damage resulting from malfunction, including loss of food product, revenue, or consequential or incidental damages of any kind.
- Equipment modified in any manner from original model, substitution of parts other than factory authorized parts, unauthorized removal of any parts including legs, or unauthorized addition of any parts.

Continued on next page

WARRANTY

Continued from previous page

- Equipment damage incurred as a direct result of poor water quality*, inadequate maintenance of steam generators and/or surfaces affected by water. Water quality and required maintenance of steam generating equipment is the responsibility of the owner/operator.
 - Equipment damage incurred as a result of not following the required maintenance schedule published in the manuals for the equipment.
-

Conclusion

This warranty is exclusive and is in lieu of all other warranties, express or implied, including the implied warranties of merchantability and fitness for a particular purpose. No person except an officer of Alto-Shaam, Inc. is authorized to modify this warranty or to incur on behalf of Alto-Shaam any other obligation or liability in connection with Alto-Shaam equipment.

**Refer to the product spec sheet for water quality standards.*



ALTO-SHAAM ASIA
Shanghai, China
Phone +86-21-6173 0336

ALTO-SHAAM CANADA
Concord, Ontario Canada
Toll Free Phone 866-577-4484
Phone +1-905-660-6781

**ALTO-SHAAM CENTRAL
& SOUTH AMERICA**
Miami, FL USA
Phone +1-954-655-5727

**ALTO-SHAAM MIDDLE EAST
& AFRICA**
Dubai, UAE
Phone +971 4 321 9712

ALTO-SHAAM MEXICO
Phone +52 1 477-717-3108

ALTO-SHAAM FRANCE, L.L.C.
Aix en Provence, France
Phone +33(0)4-88-78-21-73

ALTO-SHAAM GMBH
Bochum, Germany
Phone +49(0)234-298798-0

ALTO-SHAAM RUSSIA
Moscow, Russia
Phone +7-903-793-2331

ALTO-SHAAM.

Menomonee Falls, WI 53052-0450, U.S.A.
Telephone 800-558-8744 | +1-262-251-3800 | alto-shaam.com