# **YOLLRATH**



# HOT, COLD, FROZEN MODULAR DROP-IN

QUICK START USER'S GUIDE

# **POWERING THE UNIT ON/OFF**

#### 1. POWER ON

- Press the Power icon.
- The display screen will light up and show the last used settings for each well.
  Default setting: All wells are OFF.



#### 2. POWER OFF

 Press the **Power icon** again to turn off the unit. The display will darken, and the last-used settings for each well will be remembered.



# **SETTING UP WELLS**

Each well (identified by a number icon) can be set to one of four modes: OFF, HOT, COLD, or FROZEN.

## **SELECTING A MODE FOR A WELL**

## 1. ACTIVATE A WELL

 Press the number icon for the desired well (e.g., Well 1, Well 2). This will activate the well and display its current mode setting.



# **SELECTING A MODE FOR A WELL (CONTINUED)**

#### 2. SCROLL THROUGH MODES

- Press the number icon repeatedly to scroll through modes: OFF, HOT, COLD, FROZEN.
- Stop at your desired mode (e.g., HOT, COLD). The display will flash for 3 seconds, then go solid, confirming the mode selection.



# ADJUSTING TEMPERATURE IN HOT MODE

#### 1. SET HOT MODE FOR A WELL

Select a well" and "scroll to HOT mode.
 Once HOT is selected, the display will flash
 to allow for further adjustments. Rotate the
 control knob to increase or decrease the
 heat level.



#### 2. ADJUST HEAT LEVEL

- Push "the control knob" to activate temperature adjustment.
- **Push "the control knob"** furthermore to scroll through wells in Hot mode
- While the display flashes, rotate the control knob to increase or decrease the heat level.



# SETTING A WELL TO COLD OR FROZEN MODE

#### 1. COLD MODE

- Select a well by pressing its number icon.
- Scroll to COLD mode. The display will flash for 3 seconds, then go solid to confirm the mode.



#### 2. FROZEN MODE

- Select a well and scroll until FROZEN mode appears.
- Wait for the display to stop flashing after 3 seconds, which confirms the mode.
- In frozen mode, ensures food remains frozen and maintains optimal temperature.



# **ADDITIONAL TIPS**

Digital Readouts: Numeric temperature displays are active only in **HOT** mode. The numbers will remain blank in **OFF, COLD,** and **FROZEN** modes.

The Vollrath Company, L.L.C. 1236 North 18th Street, Sheboygan, WI 53081-3201 Tel: 800-628-0830 / Fax: 800-752-5620 / Tel: 920-457-4851 VollrathFoodservice.com

